



TARGA & T/9 BINDING SHIM MOUNTING TEMPLATE



HEEL SHIM MOUNTING TEMPLATE



TO MOUNT BINDING SHIM

- 1 Mark Three-Pin line as per ski manufacturer's recommendation.
- 2 Center 'Binding Mounting Template' on ski and align Three-Pin line with your mark.
- 3 Mark and punch the four (4) binding shim mounting holes.
- 4 Mount the binding with the screws provided. Drill, tap and glue screw holes as recommended by the ski manufacturer. Generally, a 3.5mm (9/64in) drill bit (or for metal top sheet skis 4.1mm (5/32in) drill bit) works well. Drill to a depth of at least 9mm (11/32in). Use only #3 Posi-Drive screwdriver. Tap metal top sheets for M5.5 screws.
- 5 Perform 'Cable Adjustments' as outlined.
- 6 Insert rear tab of anti-ice plate into 'Insert Slot' and secure using the #8 machine screw provided. Be sure to match left and right anti-ice plates with left and right toe-plates.

NOTE: Spare parts are found under anti-ice plates at the back of each shim (universal screws and nylock nut).

TO MOUNT HEEL SHIM

- 7 Place boot properly in mounted toe-plate and engage binding heel throw.
- 8 Center 'Heel Mounting Template' under heel of boot with arrow pointing toward ski tip. Verify that the boot positions correctly on the heel shim.
- 9 Mark and punch the two (2) heel shim mounting holes.
- 10 Mount the heel shim to the ski with the screws provided. Follow directions outlined in Step 4.
- 11 Install the high performance heel plate using the #10 machine screw provided per heel.